












1.7  x8	1.6  x1	1.8  x8	1.3  0.01	1.32  x21
1.36  x1	1.33  x1	1.18  x1	1.54  x1	
1.5  x2	1.55  x1			

Achtung!!!
Unbedingt Wandbefestigung (Teile 1.18, 1.33, 1.36) verwenden!

1	Beschlag		1
2	882*	145	2
3	310*	172**	1
4	310*	172**	1
5	260*	130	5
6	910	288/3	1
glass	871**	288**	1


4/4

VCM.

seit 30 Jahren
service@vcm-gruppe.de

Aufbauanleitung

Artikel: **VCM CD/DVD Möbel „Loposa“**



1/4

